

PAR Tablet Gen 2/3 Maintenance Guide

Tablet Care Tips

- Use only soft, clean, and dry lint-free cloths to clean the device.
- Operate the device in a place in which temperature is between -20°C (-4°F) and +50°C (122°F).
- Operation between -20°C (-4°F) and -10°C (14°F) results in limited performance.
- Avoid exposing the tablet to high temperatures, e.g. direct sunlight.
- Protect the tablet from water and moisture intake - keep connector doors closed when not in use.
- Charge to around 50% before storing.
- Store in a cool, dry place.

Charging Tips

- A charging dock or docking station is recommended to charge the tablet. If using a USB-C wall charger, ensure it has at least 18W and follows USB-C standard.
 - K8982A-02 – Docking Station Charge Only
 - K8982A-01 – Docking Station with I/O Ports
 - K8983A-01 – POS Docking Station
 - K8983-02 – Quad Tablet Charger
 - K8992-01 – AC/DC Adapter for USB-C 18W, US version with USB Cable
 - K8992-02 – AC/DC Adapter for USB-C 18W, EU version with USB Cable
 - K8992-03 – AC/DC Adapter for USB-C 18W, UK version with USB Cable
 - K8992-04 – USB C to C Cable, 1m
- Charge the device with the recommended charger in a place where temperature is between 0°C (32°F) and +50°C (122°F). Note that charging speed is reduced at higher temperatures.
- Keep Battery Between 20%–80% - avoid full charges and full discharges.
- Disconnect the charger from mains outlet when charger is not needed.
- Unplug tablet when it reached 100% charge to reduce long-term wear.


Battery Care Tips

- Batteries have life cycles. If the tablet battery run-time becomes significantly shorter than usual, the battery life might be at its end. Replace the battery when a significant loss of run time is detected.

PAR Tablet 8 and Tablet 10 - Gen 3 Only (M8995x / M8996x)

On the Gen 3 PAR Tablet, there is an option to limit maximum battery capacity to 80%. To activate this option:

- Navigate to **Start > All apps > Device Dashboard > Power > Charging limit**



Note: The Windows battery icon in the taskbar shows the following percentage ranges when the battery is charged to 80% capacity:

- PAR Tablet 8 between 70-73% depending on the battery age.
- PAR Tablet 10 between 78-82% depending on the battery age.